

General Cleaning Instructions for 3M™ Window Films

To prevent any scratching of the Window Film, do not use knives, scrapers, brushes or abrasive cleaning materials on the window. Do not rub vigorously or apply heavy pressure to the window.

Recommended commercially available glass cleaners:

- Windex® Original Glass Cleaner or similar glass cleaner
- 3M™ Glass Cleaner Concentrate #1 (Green Seal™ GS-37 Certified)
- Iso-Propyl Alcohol (can be diluted with water, 2:1) or Rubbing Alcohol
- Other: Water with a few drops of dish soap when using a squeegee.

Recommended cleaning materials and techniques:

When using these materials	And these Cleaning solutions	Use this Cleaning method
Non-abrasive, good quality paper toweling	Glass Cleaners (above)	Light wiping motion
Clean, soft cloth or microfiber cloth	None (Dry)	Light wiping motion
Clean, synthetic sponge and rubber squeegee	Water with dish soap	Light wiping motion then remove solution with the rubber squeegee

Additional Tips:

- Use a different towel for cleaning the frame/sills. Be sure to use separate cloths/sponges/buckets/squeegees for outside and inside windows.
- Low quality brown paper towels and newspaper are not recommended.
- Caution is recommended around splice areas. Wipe along the splice, not across.
- Do not leave the film wet, but squeegee it dry after cleaning.
- The detergent and water application solution can also be used for the initial cleaning of the film after installation.

Important Note for 3M™ Thinsulate™ Climate Control Window Film:

DO NOT use a **damp microfiber** cloth.

DO NOT **rub repeatedly** in one area.

DO NOT apply **heavy pressure** in any cleaning operation.

Commercial Solutions Division

3M Center, Building 220-12E-04 St. Paul, MN 55144
3M.com/windowfilm

© 3M 2020. All rights reserved.

3M is a trademark of 3M. Used under license in Canada.

All other trademarks are property of their respective owners. Revision B, May 2020. Please recycle.



General Use Instructions for 3M™ Window Films

- Do not affix tapes, suction cups, stickers, etc. to the film surface. Doing so will reduce the low emissivity properties of the film and will void your product warranty.
- Removal and replacement of window grids will reduce the low emissivity properties of the window and can damage the film.
- DO NOT WASH newly installed windows for 30 days to allow adhesion to build. This page can be left behind after window film installation, attached to the frame.

Use of 3M™ Disinfectant Cleaners

The following 3M™ Disinfectant Cleaners can be used on properly applied 3M Window Film without damaging the window film:

- 3M™ Neutral Quat Disinfectant Cleaner Concentrate 23
- 3M™ HB Quat Disinfectant Cleaner Concentrate 25
- 3M™ Disinfectant Cleaner RCT Concentrate 40
- 3M™ Quat Disinfectant Cleaner Concentrate 5
- 3M™ MBS Disinfectant Cleaner Fresh Scent Concentrate 41
- 3M™ MBS Disinfectant Cleaner Concentrate 42



Commercial Solutions Division

3M Center, Building 220-12E-04 St. Paul, MN 55144
3M.com/windowfilm

© 3M 2020. All rights reserved.

3M is a trademark of 3M. Used under license in Canada.

All other trademarks are property of their respective owners. Revision B, May 2020. Please recycle.

